


**RECOMMENDED KITE KNOT:**




Kites are supplied with approximately 2m of line - adjust the line length so the kite is about 1.5m - 2m above the crop.



150mm approx  
Swivel


Tie secure knot  
Please use the knot diagram  
(above) to ensure a secure  
fixing, double up string for  
added strength

Pull out each section of the  
7m telescopic launch pole  
and twist to lock in place



Split ring  
and swivel

Swivel halfway



Assemble the kite by inserting  
rods into pockets and rubber  
connections



Metal joining  
ferrule

Connect rods through  
loop as shown

**Ground stake** - drive  
into ground to a depth  
of approximately 50cm

**Green support disc** - fits  
over around ground stake

Slide pole over ground stake



60cm

50cm

If unusually high or gusting winds  
are forecast, the kite should be  
taken down to avoid damage

Angle pole so that the kite  
hangs well clear to avoid  
wrapping around the pole

Angle the pole in the  
opposite direction to  
prevailing winds

1.5-2m  
ABOVE CROP

PREVAILING WIND

