

WARNING

- DO NOT FLY NEAR POWER LINES
- DO NOT PLACE NEAR ROADS RAILWAY LINES ETC.

TOP OF KITE

assemble kite by inserting the brace into the tubes on the top side of the kite

tie swivels at each end of the line with a good strong knot

Pull out each section of the telescopic launch pole and twist to lock in place

tie swivels at each end of the line with a good strong knot

ground stake - drive into ground with heavy hammer to a depth of 50cm max

adjust length of the line so tip of tail is 1m above the crop

10-20°

support disc
fits around ground stake

launch pole slides over ground stake and rests on support disc

60cm

50cm

High winds

The TERROR KITE will fly well in light breezes and strong winds. If gale force winds are forecast, it is advisable to tether the kite and launch pole to a tent peg (not provided) or similar using the cleat located at the base of the launch pole.